

# Minimal Agitation Using PyroCat HD

## Notes:

If using Expansion (N+) increase ISO by 2/3 of a stop  
If using Contraction (N-) decrease ISO by 2/3 of a stop

Pre-Soak Film for 5 minutes

PyroCat likes Acid Stop Bath to be about 50% strength. ( I have been using water as a stop bath)

Set Timer to Zero ( counting upwards)

## Reading The Table

Dev	A	B	Agitate To	Rest To	Agitate To	Rest To	Agitate To	Rest	Total Time	Formula

- Dev = Type of development
- A = Amount of A pyro (mm)
- B = Amount of B pyro (mm)
- Agitate To = Agitate continuously to indicated time
- Rest To = Put tank down until indicated time

## PyroCat HD Extended Minimal Agitation

Dev	A	B	Agitate To	Rest To	Agitate To	Rest To	Agitate To	Rest To
N	3	2	2:00	9:30	9:50	17:00	17:20	24:30
N + 1	3	2	2:00	12:30	12:50	23:00	23:20	33:30
N + 2	3.5	2.5	3:00	15:00	15:25	27:30	27:55	39:00
N + 3	3.5	2.5	3:00	21:00	21:30	39:30	40:00	57:00
N + 4	4	3	5:00	20:00	20:40	35:40	36:20	50:00
N - 1	3	2	2:00	8:30	8:50	15:00	15:20	21:30
N - 2	3	2	1:30	6:30	6:50	11:50	12:10	16:30
N - 3	2.5	2	1:30	9:30	9:45	17:50	18:05	25:30
N - 4	2.5	2	1:30	8:00	8:15	14:45	15:00	21:00
N - 5	2.5	2	1:25	6:30	6:40	12:05	12:15	17:00
N - 6	2.5	2	1:25	5:30	5:40	10:05	10:15	15:15